

Bischofsheim, October 11th, 2007

NEW: Real-Time Monitoring during Pasteurisation and Bottle Cleaning
The New Wireless Datalogger Generation EBI 10 from ebro

The new innovative temperature datalogger EBI 10 from ebro Electronic in Ingolstadt/Germany uses the EBI 10 wireless technology which enables the wireless, real-time monitoring of pasteurisation and bottle-cleaning processes. It allows the operator to watch the action live on the monitor and to immediately stop a potentially faulty process. This saves work and time during validation or routine checks.

The EBI 10 logger can be used for the following applications:

- o Routine checks during pasteurisation of beer, fruit juices, milk and other food
- o F-value and PE-value calculation in food production
- o Routine checks of bottle cleaning
- o Temperature, pressure, CO₂ measurements in the beverage industry
- o Validation of processes in food production and development

The totally water- and steam-tight EBI 10 (IP68) has a temperature range from -40 to +150°C and a pressure range from 1 mbar to 3500 mbar. The memory capacity is 30,000 measured values, which allows a recording process of up to 8 hours with measuring intervals of 1 second. The temperature and pressure accuracy of ±0.1°C or ±15mbar is very high and documented in the associated ISO certificate.

Accessories and adaptors for the various processes are available. The logger is operated with the special EBI 10 interface (4-fold). It transmits on the world-wide approved frequency of 2.4 GHz and meets the IEEE radio standard 802.15.4, providing total conformity. For evaluating the recorded data, the EBI 10 wireless system is complemented by the new Winlog.pro software. Winlog.pro can be used for both routine checks and validation. The whole system complies with CFR 21 Part 11.

Legend: The new wireless data loggers EBI 10 from ebro Electronic enable real-time monitoring of processes in the food, beverage and brewing industries.

Press relations/Advertising:

EURO DOC

Mr Henri Hencke

Rheingauweg 1

D-65474 Bischofsheim

Tel.: +49 6144 41 909

Fax: +49 6144 41 909

henri.hencke@t-online.de

Please send enquiries to:

Klipspringer (ebro Service Agent UK)

Attn of **Technical Sales**

Rynor House, Farthing Road

Ipswich, Suffolk IP1 5AP

Tel.: (01473) 741 500

Fax: (01473) 747 200

info@klipspringer.co.uk

Internet: www.ebro.de